



ROZTEČ VRTÁNÍ C (mm)	DÉLKA L (mm)	ŠÍŘKA D (mm)	VÝŠKA H (mm)	SATIN CHROM	CHROM	BROUŠENÝ NIKL
96	106	15	32	<b>35112</b>	<b>157538</b>	<b>157537</b>
128	140	15	32	<b>157539</b>	<b>157541</b>	<b>157540</b>



ROZTEČ VRTÁNÍ C (mm)	DÉLKA L (mm)	ŠÍŘKA D (mm)	VÝŠKA H (mm)	SATIN NIKL	CHROM	BROUŠENÝ NIKL
64	86	7,2	19	<b>157551</b>	<b>157552</b>	<b>157553</b>
96	116	7,7	25	<b>157554</b>	<b>157555</b>	<b>157556</b>
128	150	8,2	31	<b>157721</b>	<b>157722</b>	<b>157723</b>
160	186	8,2	31,5	<b>157724</b>	<b>157700</b>	<b>157701</b>
192	218	8,2	34	<b>157702</b>	<b>157703</b>	<b>157704</b>
224	253	8,2	36	<b>157705</b>	<b>157706</b>	<b>157707</b>



ROZTEČ VRTÁNÍ C (mm)	DÉLKA L (mm)	ŠÍŘKA D (mm)	VÝŠKA H (mm)	SATIN CHROM	CHROM	BROUŠENÝ NIKL
96	106	18	32	<b>157832</b>	<b>157828</b>	<b>157824</b>
128	140	19	32	<b>157833</b>	<b>157829</b>	<b>157825</b>
160	174	20	32	<b>157834</b>	<b>157830</b>	<b>157826</b>
192	228	20	32	<b>37742</b>	<b>157836</b>	<b>37741</b>
224	257	20	32	<b>157835</b>	<b>157831</b>	<b>157827</b>

